



[www.pads4.com](http://www.pads4.com)

## PADS4 Viewer on ELO I-series 2.0

1. First time use
2. PADS4 version
3. Installation PADS4 HTML5 Launcher for ELO I-series
4. Adjust PADS4 Viewer options using the options screen
5. Supported features & limitations
6. General limitations

## 1. First time use

During the installation, you will need to configure the PADS4 Server location. Best approach is to complete the installation of the PADS4 Server first, before continuing the configuration of the device.

When you turn the device on for the first time it will open a welcome screen, continue on this screen by pressing the OK button twice.

If you have a device that has previously been used for another application, we recommend a factory reset of the device. To perform a factory reset of the device follow the next steps:

Step	Description
1	Open the settings on Android
2	Select Backup & Reset
3	Select Factory data reset
4	(Optional) Select Erase SD card
5	Select Reset tablet
6	Select Erase everything

## 2. PADS4 Version

The minimum PADS4 version that supports ELO I Series 2.0.

Minimum PADS4 Viewer version
4.9.6633 (February 28, 2018)

### 3. Installation PADS4 HTML5 Launcher for ELO I-series 2.0

#### Configuring the device for PADS4 HTML5 Launcher

By default, the network settings are disabled on the device. Also because it is a touch device you want to disable the system status bar, so you cannot close the viewer app. To configure these settings.

Step	Description
01	Open the settings on Android
02	Make sure that either Wi fi and/or Ethernet is enabled
03	To disable the status bar, select Display and check the hide status bar option
04	To disable the physical button on the device, select Physical Button Manager and uncheck the Enable Physical Buttons option

#### Install PADS4 HTML5 Launcher for Android from USB stick

Download the latest PADS4 HTML5 Launcher from: <http://go.pads4.com/?fwlink=1004>

Step	Description
01	Store the PADS HTML5 Launcher apk on a USB stick
02	Insert the USB stick into the device
03	On the device select the Apk Installer app
04	Select install and browse the USB for the apk
05	The message “Do you want to install this application” is displayed. Press the next button until the button “install” appears
06	Press the install button
07	After installation press the open button
08	The PADS4 HTML5 Launcher app will be started. Enter the location of the PADS4 Server, by specifying a domain name, IP address or pc name of the server where the PADS4 Server is running.
09	(Optional) If you changed the default server html server settings of the PADS server, open the advanced settings and specify the correct port number and host/root path.
10	Press start, the first time the app will prompt to select your home app. Select PADS4 HTML5 Launcher and select always, if you don't it will prompt the message again.

When finished the device will download the software and start the PADS4 Viewer.

A connection indicator and the generated PADS4 Viewer name are displayed in the lower left corner of the screen. If the connection fails, open the Viewer log from the options screen (see step 4).

#### Updating PADS4 HTML5 Launcher from USB stick

Step	Description
01	Put a newer version of the PADS HTML5 Launcher apk on a USB stick
02	Insert the USB stick into the device
03	Open the viewer settings
04	Select launcher settings
05	Click on the folder icon in the right bottom corner
06	Navigate to the newer apk on the usb stick, by selecting the storage folder and then the usb_storage folder
07	Select the apk
08	The message “Do you want to install an update to this existing application” is displayed.
09	Press the install button. The PADS4 HTML5 Launcher should automatically start when installed.

## 4. Adjust PADS4 Viewer options using the options screen

PADS4 Viewer options can be adjusted directly on the display.

To enter the options screen on the device itself, hold the left mouse button down or touch the screen for 3 seconds.



















Changing Viewer options can also be managed afterwards from a central location using the PADS4 Agent.

To access the Android settings menu when the viewer is running:

Step	Description
01	Open the viewer settings
02	Click on the Launcher Setting button
03	Click on the gear icon in right bottom corner
04	The Android settings open If the Hide Status Bar option is turned on, the only way to leave the Android setting is to restart the device, by disconnecting the power.

## 5. Supported features & limitations

The following features and limitations are related to ELO I-series 2.0.

Area		Support
Display models		ELO I-series 2.0 *ELO series based on Microsoft Windows are fully compatible with the PADS4 Windows Viewer. Please check the <a href="#">Windows documentation</a> for more info.
Portrait mode		Supported
HTTPS		Supported
Video		Recommended maximum of 4x HD video (30fps) Recommended maximum of 2x HD video (60fps)
		Support streaming *HTTP streaming
Image		Support for JPG, PNG, BMP, GIF
Text		Supported
Line		Supported
Shape		Supported
Scrolling text		Supported
Formatted Text		Supported
Flash		Supported *there is no support to detect end of flash presentation when playing. Functions such as play once next page and detect end of presentation are not supported
Table		Supported
Interactive Button		Supported (only for XDS series that support interactivity) *Mouse cursor options not supported *Interactive Data filter & sort dialog window not supported
Playlist		Content from PADS4 Content Library & URL supported
Web		Supported *Usage of the interactive Address Bar not supported
Colors		Supported *Texture and pattern colors are not supported
Data providers		All PADS4 data providers (70+) supported

Transitions		Supported *Horizontal and vertical blinds not supported *Increasing circle, splitters and sliced circle not supported
Rules		Presentation, Page and Element rules supported
Offline Content Library storage		PADS4 Content Library is stored on the local device
MD5 check		PADS4 Content Library file integrity is checked during synchronization using MD5
Offline Schedules		All scheduled presentations are cached local
Offline Data		Data retrieved from data providers is cached local
Property bindings		Supported
Viewer variables		Supported
Software updates		Automatic software updates supported
PADS4 Agent		PADS4 Agent supported. *The following Viewer functionality: Screenshot, Viewer Log, Synchronization Log, Viewer Settings, System Info, Viewer Blackbox and Proof of Play
		Refresh device supported
		Display current connection state supported
		Viewer variables supported
		Monitoring & Alerts supported *The following functionality: Network connections

## 6. General limitations

Data Providers	Data providers always make use of the PADS4 data server. A HTML5 Viewer is not able to read the information itself from the source.
Content Library	Support for content from PADS4 Content Library . *Content from file is not supported when pointing to a local disk location.
Proof of Play	Local storage limitation of max. 50.000 records on the HTML5 Viewer during offline period. When the 50.000 is hit, the oldest value will be removed first.
Storage capacity	Storage capacity for content differs per device and browser.